

# GNIRS

## Service and Calibration Manual

### Table of Contents

<b>1</b>	<b>Introduction.....</b>	<b>1</b>
<b>2</b>	<b>Safety.....</b>	<b>3</b>
<b>3</b>	<b>Instrument Description .....</b>	<b>5</b>
<b>4</b>	<b>Instrument Preparation and Installation [Overview] .....</b>	<b>16</b>
4.1	Electronics and Software .....	17
4.1.1	Thermal Enclosure Power-On.....	17
4.1.2	Software Start-up .....	21
4.1.3	Shutdown .....	25
4.2	Vacuum and Cryogenic Procedures .....	26
4.2.1	Vacuum and Cryogenic Safety.....	26
4.2.2	Evacuation and Pressurization .....	27
4.2.3	Cryocooler Operation.....	32
4.2.4	Cool-Down Procedure .....	35
4.2.5	Warm-Up Procedure .....	41
4.2.6	Backfilling the Instrument Prior to Maintenance.....	43
4.3	Instrument Installation and Removal .....	44
4.3.1	Installation on Side Looking Port .....	44
4.3.2	Installation on Up Looking Port.....	50
4.3.3	Measuring and Adjusting Tilt/Focus.....	56
4.3.4	Default Ballast Weight Distribution .....	60
4.3.5	Definition of Ballast Weight Stations .....	63
<b>5</b>	<b>Maintenance and Common Procedures.....</b>	<b>68</b>
5.1	Maintenance Procedures .....	68
5.1.1	Maintenance Intervals .....	68
5.1.2	Cryocooler Maintenance .....	69
5.1.3	Changing Molecular Sieve.....	71
5.1.4	Entrance Window Cleaning and Replacement.....	72
5.2	Common Procedures .....	74
5.2.1	Changing Filter .....	75
5.2.2	Changing Slit Mask .....	77
<b>6</b>	<b>Troubleshooting Procedures.....</b>	<b>80</b>
6.1	Diagnostic Windows.....	81
6.2	Mechanical Operation/Diagnosis.....	93
6.2.1	Home Switch.....	93

6.2.2	Limit Switch.....	94
6.2.3	Stall .....	94
6.3	Cooling System Diagnostics .....	95
6.4	Vacuum Troubleshooting.....	97
6.4.1	Diagnostic Techniques.....	97
6.4.2	Ambient Temperature Vacuum Problems.....	97
6.4.3	Cold Vacuum Problems .....	99
6.5	Component Controller Thermal Enclosure Troubleshooting.....	100
6.5.1	WFS Stepper Motor Control (Crate 1).....	104
6.5.2	Stepper Driver Chassis (Crate 2) .....	105
6.5.3	VME Chassis (Crate 3) .....	106
6.5.4	Ancillary Crate (Crate 4).....	108
6.5.5	Warmup Controller .....	111
6.6	System Failures .....	114
6.6.1	Power Failures .....	114
6.6.2	Coolant Failure.....	115
6.6.3	Network Failure .....	115
6.6.4	Cryocooler Failures .....	115
6.6.5	Really Bad Weather .....	116
<b>7</b>	<b>Calibration Procedures .....</b>	<b>117</b>
7.1	Mechanism Calibration .....	117
7.1.1	Establishing a Datum .....	117
7.1.2	Mechanism Configuration .....	118
7.1.3	Focus Calibration .....	121
7.1.4	Pupil Viewer Centering.....	122
7.2	Software Configuration .....	122
7.2.1	Filter Change.....	122
7.2.2	Position Optimization .....	123
7.2.3	Slit Mask Change.....	123
7.2.4	Home Switch Change .....	123
7.2.5	Grating Optimization .....	123
7.3	Programming the Bench and Warmup Temperature Controllers .....	124
7.3.1	Bench Temperature Controller.....	125
7.3.2	Dewar Warmup Controller .....	126
7.3.3	Temperature Sensor Locations.....	127
7.3.4	Temperature Diode Calibration .....	127
7.4	Flexure Compensator Adjustment .....	127
7.4.1	Coordinate Systems.....	128
7.4.2	Flexure Measurement.....	128
7.4.3	Flexure Correction .....	129
7.4.4	Correction Procedure .....	131
<b>8</b>	<b>Instrument Disassembly Procedures.....</b>	<b>132</b>
8.1	General Considerations .....	132
8.1.1	Safety .....	132

8.1.2	Sub-System Disassembly .....	132
8.1.3	Assembly Overview Checklist .....	134
8.2	Preparation for Disassembly .....	142
8.2.1	Introduction to Disassembly Procedures.....	142
8.2.2	Definition of Instrument Orientations.....	145
8.2.3	Handling Fixtures.....	146
8.2.4	Lifting and Handling Instrument.....	149
8.2.5	Orienting Instrument Horizontally.....	151
8.2.6	Instrument Warm Up .....	152
8.2.7	Instrument Pressurization to Atmospheric Pressure .....	152
8.3	External Structure Removal and Installation .....	153
8.3.1	Grounding and Removal of Cabling, Helium Lines, and Glycol Coolant Lines from Thermal Enclosures .....	153
8.3.2	Thermal Enclosures .....	155
8.3.3	Removal of Cabling, DPS, Helium Lines, and Glycol Coolant Lines from Bulkhead.....	158
8.3.4	Instrument Mounting Trusses .....	160
8.4	Internal Structure Removal .....	162
8.4.1	Detector Assembly & Detector Focus Assembly.....	162
8.4.2	Aft Dewar Shell and Molecular Sieve .....	166
8.4.3	Forward Dewar Shell and Aft Bulkhead.....	169
8.4.4	Forward and Aft Active Shields.....	172
8.4.5	Pre-Slit Bench .....	174
8.4.6	Rotating Instrument Vertically for Main Bench Removal.....	177
8.4.7	Cryogenic Cooler Module Removal .....	180
8.4.8	Main Bench Removal .....	184
8.4.9	Main Bench Active Shield Removal.....	190
8.4.10	Mounting Main Bench on Handling Cart .....	193
8.4.11	Summary of Installation Procedures .....	197
8.5	Sub-system Removal.....	206
8.5.1	On Instrument Wave Front Sensor Bench .....	206
8.5.2	Collimator Mirror Assembly.....	208
8.5.3	Long Camera Fold Mirror Mount .....	211
8.5.4	Inverting Main Optical Bench.....	213
8.5.5	Acquisition Mirror .....	217
8.5.6	Camera Turret .....	219
8.5.7	Prism Turret .....	223
8.5.8	Grating Turret .....	227
8.5.9	Filter Wheel .....	232
8.5.10	Slit / IFU Module .....	234
8.6	OIWFS Components .....	237
8.6.1	Introduction.....	237
8.6.2	OIWFS Field Lens .....	238
8.6.3	Filter Wheel and Detector Focus Assembly.....	240
8.6.4	Gimbal Mirror Assembly.....	245
8.6.5	Combo Lens Mount .....	246

8.6.6	Installation of OIWFS Bench.....	247
8.7	Optics Removal and Reinstallation.....	248
8.7.1	Procedures for Handling Optics.....	248
8.7.2	Camera Lenses and Mirrors .....	250
8.7.3	Pickoff Mirror .....	255
8.7.4	Foreoptics Module Assembly and Offner .....	255
8.7.5	Collimator Mirror Assembly.....	258
8.7.6	Prisms.....	260
8.7.7	Gratings.....	261
8.7.8	Acquisition Mirror .....	264
8.7.9	Entrance Window.....	265
8.8	Detector Handling .....	268
8.8.1	Detector Assembly & Detector Focus Assembly.....	268
8.8.2	To Remove the OIWFS Detector Assembly from the Focus Drive...273	
<b>9</b>	<b>Shipping Container.....</b>	<b>276</b>
9.1	Procedures to Remove Instrument from Shipping Container .....	276
9.1.1	End Panel Removal.....	276
9.1.2	Shock Mount Deflation & Removal .....	277
9.1.3	Instrument Hold Down Bolt Removal .....	278
9.1.4	Top Panel Removal.....	279
9.1.5	Lifting Instrument from Container.....	282
9.2	Procedures to Install Instrument into Shipping Container .....	284
9.2.2	Lifting Instrument into Shipping Container.....	285
9.2.3	Instrument Hold Down Bolt Installation.....	286
9.2.4	Shock Mount Inflation .....	287
9.2.5	Shock Mount Installation.....	287
9.2.6	Top Panel Installation .....	288
9.2.7	Shock Mount Inflation .....	290
9.2.8	End Panel Installation .....	291
	APPENDIX A: Checklists .....	292
	APPENDIX B: Instrument Configuration File Listings .....	298